## How to install the New Bi-Polar Spring Gate #BP38C with the same tape as your fence



Insert the tape through the slot of the plastic buckle



Now insert the tape back through the bigger slot



Press the two sections of tape together at the bottom of the buckle. The end of the tape is in the back.



Insert the pin roller at the front of the 2 layers of tape



Pull the pin roller to slide and pinch the tapes



Pull the 2 tape sections together ...



... to block the pin roller



Use one round clip so the tape doesn't slip.



For easy manipulations 3 strands of tape is a maximum